


Ex9M1 (16A~125A)




Circuit breaker
Jistič
Istič
Wyłącznik kompaktowy
Intrerupator automate
Leistungsschalter
Disjoncteur
Автоматический выключатель

NOARK

A





B



C

		N	
		3P	4P
	M4×75	4	4
	φ 4/6	4	4
	φ 4/6	4	4
	M4	4	4
		4	6

mm	mm
	
	


D Test

Mounting instructions
Montážní návod
Montážne inštrukcie
Instrukcja montażu
Instrucțiuni de asamblare
Montageanweisung
Instructions de montage
Инструкция по монтажу
Monteringsanvisning
Istruzioni di montaggio
Instrucciones de montaje
Összeszerelési útmutató

Asennusohjeita
Montage-instructies
Instruções de montagem
Navodila za montažo
Οδηγίες Εγκατάστασης
Инструкции за инсталиране
Monteringsvejledningen
Montažu upute
Surinkimo instrukcijos
Instalēšanas instrukcijas
Скупщина упутство
Paigaldusjuhendid

Caution: Installation by electricians only
Varování: Montáž pouze osobou s elektrotech. kvalifikací
Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou
Uwaga: Montaż tylko przezu prawnionych instalatorów
Atenție: Instalare numai de catre electricieni
Vorsicht: Montagenur durch Elektrofachkräfte
Attention: Montage uniquement par un électricien
Осторожно: Монтаж только электрика

NOARK



E

