

RCBO

Proudový chránič s nadpr. ochr.

Prúdový chránič s nadpr. ochr.

Wyłącznik nadprąd. z mod. różnicowoprąd.

Intrerupator diferencial/automate

FI/LS-Schalter

Interrupteur differential

ДАВ

NOARK

Mounting instructions

Montážní návod

Montážne inštrukcie

Instrukcja montazu

Instrucțiuni de asamblare

Montageanweisung

Instructions de montage

Инструкция по монтажу

Monteringsanvisning

Istruzioni di montaggio

Instrucciones de montaje

Összeszerelési útmutató

Asennusohjeita

Montage-instructies

Instruções de montagem

Navodila za montažo

Οδηγίες Εγκατάστασης

Инструкции за инсталиране

Monteringsvejledningen

Montažu upute

Surinkimo instrukcijos

Instalēšanas instrukcijas

Скупштина упутство

Paigaldusjuhendid

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotech. kvalifikací

Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou




Uwaga: Montazty lko przezu prawnionych instalatorów


Atenție: Instalare numai de catre electricieni





Vorsicht: Montagenur durch Elektrofachkräfte

Attention: Montage uniquement par un électricien


Осторожно: Монтаж только электрика





	 Z2
 s (mm ²)	1.5-25mm ²
 (Nm)	≥2Nm




Test monthly
 Testovat měsíčně
 Testovať mesačne
 Test miesięcznie
 Test lunar
 Test månedlige
 Test mensuelle
 Испытание ежемесячно



Green
 Zelená
 Zielony
 Verde
 Grün
 Vert
 Зеленый



Red
 Červená
 Czerwony
 Roşu
 Rot
 Rouge
 Красный



NOARK



Printed with environment-friendly paper

Copyright Noark. All Rights Reserved

www.noark-electric.eu